ArcticChill 88 Exceptional Capacity

Delivers 30 - 40 Litres Per Hour Of Chilled Water Below 12C







WATER COOLERS BOILERS

refreshingly different

- Direct chill cold water cooler
- Single dispensing button for Chilled water
- Can be fitted with overflow kits & mains drainage
- Fits our standard cowling and wall Bracket
- WRAS approved
- FloodGuard inlet solenoid protects the cooler against large scale flooding
- Impressive 23cm dispensing height

ArcticChill 88 Exceptional Capacity

Accessories For The ArcticChill 88

Filter Housing With Carbon Block Candle & Nanofilter.



Installation Rail With Filter. Includes Compression Fitting, 1-Micron Green Filter, Water Block, Copper Pressure Reducing Valve & Non-Return Valve.

FloodGuard - Inlet Solenoid Only Opens To Allow Water Into The Cooler, When Water Is Dispensed. By Remaining Closed All Other Times It Protects The Cooler Against Leaks.



Mains Drainage - Connect The Drip Tray To Mains Drainage. Can Be Supplied With A Pump, To Pump The Water Over 50m & A Rise Of Sm.

3 Litre Overflow Kit Connects The Drip Tray To A 3 Litre Alarmed Overflow Container. The Container Has A Tap To Empty Without Removing It.



10 Litre Overflow System With Alarm To Signal When Full . (Factory Fitted).





www.aafirst.co.uk


A Pumped Main Drainage System Pumps The Waste Water From The Drip Tray Over A Distance Of 100m &

A Rise Of 5m. (Factory Installed).



Cowling To Fix The Cooler Securely To The Wall (Supplied Separately).





Local Distributor