

**Bottle Filler Thats Easy To Install,
Cost Effective & Tough**

FONT 30

Wall- Mounted Bottle Filler With Bubbler



**"Accessible
Drinking Water
For All"**

Description

FONT 30 (Unchilled Mains Water)

Easy to install, cost effective & tough, a bottle filler with bubbler for inside, & covered outdoor installation in schools, institutions & public access spaces.

- A solid Manual Push Button Bottle Filler and JoyStick Bubbler, made of high grade Stainless Steel.
- The FONT 30 connects straight into the mains supply providing unchilled water.
- We recommend to use our Plumbing and Filter Kit to connect to the mains. The FONT30 can also be connected to a our UC800 Undersink Chiller to dispense chilled water.

Easy to install, simple to maintain and cost effective, the FONT 30 meets the growing need of accessible Drinking Water for all.

Specification

Dimensions (MM): 750H, 330W, 370D
Weight (Kg): 12.5

Bubbler:

To increase/decrease the water flow remove the outer Bubbler spout and then adjust with a screw driver



AAFIRST
WATER COOLERS
& BOILERS



CE RoHS

FONT 30

Wall- mounted Bottle Filler With Bubbler

Installation Instructions

Font30

Step 1

Unpack the FONT30 and check that all parts are included in the box

Step 2

Connect the Bubbler to the basin as shown (1). Ensure that the Bubbler is pointing in the right direction and that all the screw connections are tight

Step 3

Connect the Bottle Filler to the back plate, with the screws provided, as shown (2). Again ensure that all the connections are tight

Step 4

Connect the Inlet Hose (3) to the Bottle Filler (4) and Bubbler (5)

Step 5

Install the Wall Bracket (8) on which the FONT 30 will hang. Use conventional wall fixings depending on the type of wall. Drill two more holes for two fixing screws at the bottom of the FONT 30 frame

Step 6

Connect the drain to the basin. Use an allen key to tighten the drain screw to the basin (6). Assemble the drain as shown (7). Tighten the tail pipe, P-trap and drain pipe by hand before you tighten them with a wrench

Step 7

Hang the FONT 30 on the Wall Bracket and secure the frame to the wall with the two fixing screws at the bottom of the frame. Screw the bottom plate to the frame with the screws provided

